

Dishwashers

DIHR Dish Washer HT11 Hood Type

An integral part of any busy hotel or restaurant kitchen. Use the complete DIHR 5 step dishwashing system to provide a constant supply of sparkling clean crockery and cutlery on demand.


- Step 1:** Rinse off your soiled crockery and cutlery with the pre-rinse spray (B).
- Step 2:** Stack your dirty crockery and cutlery into the glass or dish racks (C) and slide into the dishwasher to commence the wash cycle.
- Step 3:** On completion of the wash cycle, slide out the rack and the just washed items will air dry in minutes.
- Step 4:** Stack the just washed items still in the racks onto your rack dolley (D) for safe and damage free storage of your valuable crockery and glasses.
- Step 5:** Wheel your rack dolley to your storage or setup area, ready to be wheeled into action on demand.



DIHR Hood Type Dish washer HT11

Specifications: DIHR Dish Washer HT11

Voltage:	• 400V - 3phase
Power:	• 12kW
Wash Pump:	• 0.11kW
Dimensions:	• 690 x 722 x 1400mm
Weight:	• 115kg
Basket Size:	• 500 x 500mm
Output:	• Approx 60 racks per hour
Wask Tank:	• 30Lt



Code	Ref	Description	Qty
DWD0011	A	Dish Washer DIHR - HT11 Hood Type - Includes 2 Racks	
DRA5001	C	Dish Rack - All Purpose - Plate	
GRC5025	D	Glass Rack - 25 Compartment (Blue)	
DRC4002	E	Dishwashing Rack - Rack Dolley with Plug	
PRS0001	B	Overhead Pre Rinse Spray (Includes mixer taps)	

- Gavity drain on all dishwashers
- Drain Pump optional

Refer to pages 70 and 71 for all your rack requirements.

To eliminate breakages, use racks as storage racks to save time , money and handling.